




Item	Parts No.	Description
101	201105201A	Bolt Assy
102	2040104050100	Hex.soc.hd.screw
103	1136903109011	Cap
104	2001091000	Seal
105	1136000100013	Compression Spring
106	2152011	O - Ring
107	1139903100011	Collar
108	3203330000	O - Ring
109	1131C03147011	Ring
110	2152041	O - Ring
111	101510901	Hd.valve Piston
112	2041108031200	O - Ring
113	1132M03147011	Packing
114	100112002	Piston Ring
115	3202220000	O - Ring
116	1120404500031	Driver Unit
117	2041105050300	O - Ring
118	1132003100011	Cylinder
119	100111701	Cylinder Ring
120	1132703147011	Bumper
121	1138804547011	Driver Guide
201	2152035	O - Ring
202	2017291000	Trigger Valve Head
203	100122001	Spring
204	101520301	Plunger
205	2152060	O - Ring

Item	Parts No.	Description
205A	2041102010310	O - Ring
206	3201260000	O - Ring
207	101520601	Plunger Cap
208	2040400041000	Spring Pin
209	101520801	Trigger
210	246212	Spring Pin
211	101521501	Secondary Trigger
212	246352	Spring Pin
301	1123003166011	Gun Body Unit
302	1132H03147011	Gasket
303	1134603113011	End Cap
304	20110418C12	Hex.soc.hd.bolt
305	1132303147011	Bracket
306	1139403147011	Guide Plate
307	2027810047	Dusty Cover
308	2301021	Air Plug
309	2041109020600	O - Ring
401	20110414C12	Hex.soc.hd.bolt
402	246182	Spring Pin
403	1135104547031	Driver Guide Cover
404	1138002247041	Gasket
405	1139104547011	Magazine B
406	1124104547011	Driver Guide Unit
407	1139502247011	Rod
408	1136702247021	Pusher Spring
409	1136304547011	Pusher

Item	Parts No.	Description
410	1139002247011	Protecting Hood Cover
411	20710516C12	Counter Sunk Screw
412	2501052	Lock Nut
413	20110408C12	Hex.soc.hd.bolt
414	1130503147011	Stopper
415	2021640A00	Latch Pin
416	2020770A00	Spring
417	1134303147022	Latch
418	226105	E - Ring
419	101543201	Safety Guide
420	100720201	Safety Spring
421	1133003147021	Safety
422	1133402247021	Relief Plate
426	3000040000	Hex.soc.hd.bolt
427	3002190200	Bolt Assy