




Item	Parts No.	Description
101	1220100130021	Housing
201	1230400111012	Regulator
202	1230500100011	Valve Stem
203	2152129	O - Ring
204	2041109010500	O - Ring
205	2040301150100	S - Ring
206	1230600147011	Seal
207	1230700147012	Tip Valve
208	1230800147011	Conical Spring
209	1230900147031	Air Inlet
210	2040400062400	Spring Pin
211	1231001100012	Trigger
301	1231100147011	Front Ring
302	2041200000930	Bearing
303	1231200100011	Front Bearing Plate
304	1231301100011	Rotor
305	1231401100011	Blades
306	1231501100011	Cylinder
307	2040401052300	Line-Up Pin
308	1231600100011	Rear Bearing Plate
309	2041200000540	Bearing
310	1231700147011	Rear Ring
311	1231900147011	Middle Ring
312	1232000147011	Washer
313	1232100100021	Lock Ring Seal
314	1232202147011	Motor Shaft Balancer

Item	Parts No.	Description
315	2040701010100	Rotor Key
316	2041201000100	Bearing
317	1232300147011	Bearing Shield
318	225101	Snap Ring
319	1232400147011	Balancer Shaft
320	1232500147021	Vacuum-Shroud
321	2040303400100	Snap Ring
322	1235000100011	Bearing Seal
323	2280100139011	"6""Pad-6 Holes Hook"
324	1234000147011	Heat Isolation Washer
401	1232700100011	Muffler Screw
403	1233000147011	Vacuum Adapter-Self Vac
404	1238700147011	Connector
405	1238900100011	Dowel Pin