




Index No.	Part No.	Description	Qty	Index No.	Part No.	Description	Qty
1	9301S01	Valve Screw	1	27	9301S27	Screw	2
2	9301S02	O Ring	1	28	9301S28	Housing	1
3	9301S03	O Ring	1	28A	9301S28A	Plastic Wrapp	1
4	9301S04	Air Controller	1	29	9301S29	Piston Ass'	1
5	9301S05	Valve spring	1	30	9301S30	Set Screw	2
6	9301S06	Valve Stem	1	31	9301S31	Service Wrench(2mm)	1
7,7A	9301S07	O Ring	1	32	9301S32	Guide Plete	1
8	9301S08	Valve Bushing	1	33	9301S33	Blade Chuck	1
9	9301S09	Inlet Bushing	1	34A	9301S34A	Work Guide (long)	1
10	9301S10	Cap Screw	4	34B	9301S34B	Work Guide (short)	1
11	9301S11	Washer	1	35A	9301S35A	Blade (32T)	1
12	9301S12	Lever Pin	1	35B	9301S35B	Blade (24T)	1
13	9301S13	Throttle Lever	1	36	9301S36	Service Wrench(4mm)	1
15	9301S15	Valve Case	1	38	9301S38	Screw	1
16	9301S16	Bush	1	39	9301S39	Upper Wear Shoe	1
17	9301S17	Cylinder	1	40	9301S40	Blade Guide	2
18	9301S18	Valve Sleeve	1	41	9301S41	Bridge	1
19	9301S19	Actuate Valve	1	42	9301S42	Front Bumper	1
20	9301S20	washer	1	43	9301S43	Rear Bumper	1
21	9301S21	Cap Screw	2	44	9301S44	Rel Pin	2
22	9301S22	Gasket	1	45	9301S45	spring	1
23	9301S23	Valve Block	1	46	9301S46	Packing	1
24	9301S24	Set Screw	2	47	9301S47	Packing	1
25	9301S25	Bush	2	48	9301S48	Packing	1
26	9301S26	Chuck Cover	1	49	9301S49	Set Screw	1