




| NO. | Part No. | Description        | Qty | NO. | Part No. | Description           | Qty |
|-----|----------|--------------------|-----|-----|----------|-----------------------|-----|
| 1   | 1203S01  | Hose Adapter       | 1   | 19  | 1203S19  | Actuator Gear         | 1   |
| 2   | 1203S02  | Rear Head          | 1   | 20  | 1203S20  | Front Head            | 1   |
| 3   | 1203S03  | Parking            | 1   | 21  | 1203S21  | Socket Cap. Ser.      | 7   |
| 4   | 1203S04  | Valve              | 1   | 22  | 1203S22  | Knob Assembly         | 1   |
| 5   | 1203S05  | O-ring             | 2   | 23  | 1203S23  | Adj. Shaft            | 1   |
| 6   | 1203S06  | O-ring             | 2   | 24  | 1203S24  | Plunger               | 1   |
| 7   | 1203S07  | Socket Ser.        | 1   | 25  | 1203S25  | Phillips Rd. Hd. Ser. | 2   |
| 8   | 1203S08  | Switch Control Bat | 1   | 26  | 1203S26  | Trigger               | 1   |
| 9   | 1203S09  | O-Ring             | 1   | 27  | 1203S27  | Handle                | 1   |
| 10  | 1203S10  | Spring             | 1   | 28  | 1203S28  | Roll Pin              | 1   |
| 11  | 1203S11  | Body Assembly      | 1   | 29  | 1203S29  | Flat Headle Ser.      | 4   |
| 12  | 1203S12  | Piston Ring        | 2   | 30  | 1203S30  | Side Strape           | 2   |
| 13  | 1203S13  | Piston             | 2   | 31  | 1203S31  | Phillips Rd. Hd. Ser. | 8   |
| 14  | 1203S14  | Wear Button        | 8   | 32  | 1203S32  | Carrier Assembly      | 1   |
| 15  | 1203S15  | Bearing            | 4   | 33  | 1203S33  | Phillips Rd. Hd. Ser. | 2   |
| 16  | 1203S16  | Shaft              | 2   | 34  | 1203S34  | Pad Assembly          | 1   |
| 17  | 1203S17  | Gear               | 1   | 35  | 1203S35  | Hex. Nut              | 2   |
| 18  | 1203S18  | Actuator Valve     | 1   |     |          |                       |     |