




NO.	Part No.	Description	Qty	NO.	Part No.	Description	Qty
1C	6304R01	1/4" Nosepiece	1	26	6304R26	Piston Head Lock Screw	1
1A	6304R01-1	5/32" Nosepiece	1	27	6304R27	Plunger Rod	1
1B	6304R01-2	3/16" Nosepiece	1	28	6304R28	O-Ring Seal	1
2	6304R02	Head	1	29	6304R29	Damping Ring	1
3	6304R03	Jaw Housing	1	30	6304R30	Trigger Arm	1
4	6304R04	Jaws	3	31	6304R31	Air Cylinder Body	1
5	6304R05	Jaw Pusher	1	32	6304R32	Roll Pin	1
6	6304R06	Spring	1	33	6304R33	O-Ring Washer	1
7	6304R07	Nut	1	34	6304R34	Air Cylinder Cap	1
8	6304R08	Jaw Housing Coupler	1	35	6304R35	Clip	1
9	6304R09	Wiper Ring	1	36	6304R36	Value Spring	1
10	6304R10	"X" Ring Seal	2	37	6304R37	Value Plate	1
11	6304R11	"X" Ring Washer	1	38	6304R38	Valve pressure Spring	1
12	6304R12	Hydraulic Section	1	39	6304R39	O-Ring Seal	3
13	6304R13	"X" Ring Seal	1	40	6304R40	Wrench	1
14	6304R14	Hydraulic Plunger	1	41	6304R41	Screw Plug	1
15	6304R15	O-Ring Seal	1	42	6304R42	Washer	1
16	6304R16	Guide Washer	1	43	6304R43	Sealing Washer	1
17	6304R17	Ring Washer	1	44	6304R44	1/4" Air Inlet Fitting (F)	1
18	6304R18	Ruetum Spring	1	45	6304R45	Air Inlet Plug	1
19	6304R19	Hydraulic Rod Guide	1	46	6304R46	Washer Seal	1
20	6304R20	Lock Nut	1	47	6304R47	O-Ring Seal	1
21	6304R21	Screw Plug	1	48	6304R48	Plastic Bottle	1
22	6304R22	Front Piston Head Disc	1	49	6304R49	Valve Tube	1
23	6304R23	Piston Head Packing Ring	1	50	6304R50	Rubber Cushion	1
24	6304R24	Rear Piston Head Disc	1	51	6304R51	O-Ring Seal	1
25	6304R25	Spring Washer	1	52	6304R52	O-Ring	1