




Hose and Bag included

Item	Parts No.	Description
101	122010013002-1	Housing
201	123040011101-2	Regulator
202	123050010001-1	Valve Stem
203	204110901040-0	O - Ring
204	204110901050-0	O - Ring
205	204030115010-0	S - Ring
206	123060014701-1	Seal
207	123070014701-4	Tip Valve
208	123080014701-1	Conical Spring
209	123090014703-1	Air Inlet
210	204040006240-0	Spring Pin
211	123100110001-2	Trigger
301	123110014701-1	Front Ring
302	204120000094-0	Bearing
303	123120110001-1	Front Bearing Plate
304	123130013902-1	Rotor
305	123140010003-1	Blade
306	123150110001-1	Cylinder
307	204040105230-0	Line-Up Pin
308	123160110001-3	Rear End Plate
309	204120000055-0	Bearing

Item	Parts No.	Description
310	123170014701-1	Rear Ring
311	123190014701-1	Middle Ring
312	123200014701-1	Washer
313	123210010002-1	Lock Ring Seal
314	123220014714-1	Motor Shaft Balancer
315	204070101010-0	Rotor Key
316	204120100010-0	Bearing
317	123230014701-1	Bearing Shield
318	204030110010-0	Snap Ring
319	123240014701-2	Balancer Shaft
320	123250014702-1	Vacuum-Shroud
321	204030340010-0	Snap Ring
322	123500010001-1	Bearing Seal
323	122470010150-2	6"Pad 6 Holes Hook
324	123400014701-1	Heat Isolation Washer
325	1233M-0110001-1	Bearing Seal
401	123270010001-1	Muffler Screw
403	123300014701-1	Vacuum Adapter-Self Vac
404	123870014701-1	Connector
405	123890010001-1	Dowel Pin